

# iSeed®

## Settings for Maredo GT 410



### Calibrations for Maredo GT 410

#### Guidelines & remarks

- The majority of these machines are used on greens and in most cases with bentgrasses.



BARE SEED	
MACHINE SHAFT SETTING	KG/HA
Bentgrass	
20/60	2,7
40/40	8,1
Fescue	
20/60	2,2
40/40	6,6

iSEED®	
MACHINE SHAFT SETTING	KG/HA
Bentgrass	
20/60	3,0
40/40	7,2
Fescue	
20/60	3,5
40/40	9,8

iSEED® / BARE SEED	
MACHINE SHAFT SETTING	RATIO
Bentgrass	
20/60	1,1
40/40	0,9
Fescue	
20/60	1,6
40/40	1,5



#### DLF-TRIFOLIUM

Ny Oestergade 9 - DK 4000 Roskilde  
 Tel. +45 46 33 03 00 - Fax +45 46 32 08 30  
 www.dlf.com - dlf@dlf.com

The above calibration is an example. Always make your own calibrations before sowing!